





TECHNOLOGY IN MOTION

The work described in these installation instructions may only be carried out by specialist companies.



Read thoroughly before use/installation!  
Keep for future reference!





# MACO PROTECT DOOR LOCKS



## INSTALLATION INSTRUCTIONS

A-TS Comfort motor, access solutions and interfaces

## Legends and abbreviations

	DM	Backset dimension
	E	Distance
	GM	Handle size
		Profile front edge



## Table of contents

1. Notes for using these installation instructions.....	5
2. Safety and warning notices.....	7
3. Technical data .....	8
3.1 Motor for 3-latch automatic lock (104130) .....	8
3.2 Comfort Motor 2.0 A-TS (482967) .....	9
3.3 Bluetooth module for A-TS + M-TS “BLE Module” .....	10
3.4 UPS (uninterruptible power supply).....	10
3.5 Power supply.....	10
4. Certificates and proof of performance.....	11
5. Intended use .....	12
6. Reasonably foreseeable misuse.....	12
7. Instructions for the processing of electrical and electronic components.....	13
8. Installation of the motor on 3-latch automatic lock.....	14
9. Access solutions & interfaces .....	15
9.1 Overview.....	15
9.2 BLE module connection options for control via MACO SMARTPHONE APP.....	16
9.3 Keypad .....	17
9.4 dLine touchkey .....	18
9.5 dLine touchkey (hinge side).....	19
9.6 Somfy Smart lock controller .....	20
9.7 Frame-side circuit diagram.....	21
9.8 Touch pulse circuit diagram.....	22
9.9 Changeover switch circuit diagram (motorised day position).....	23
9.10 UPS (uninterruptible power supply) connection diagram .....	24
9.11 Plunger contact secureConnect dLine touchkey .....	25
10. Timber profile milling images .....	26
10.1 Keypad milling image .....	26
10.2 dLine touchkey milling image.....	27
10.3 Motor milling image.....	28
10.4 Motor milling image with BLE module .....	29
10.5 Cable transition for opening angle $\leq 110^\circ$ , 12 clearance.....	30
10.6 Cable transition for opening angle $\leq 180^\circ$ , 4 clearance, 12 clearance.....	31
10.7 Plunger contact.....	32

11. PVC profile milling images .....	33
11.1 Keypad milling image .....	33
11.2 dLine touchkey milling image .....	34
11.3 Motor milling image.....	35
11.4 Cable transition for opening angle $\leq 110^\circ$ , 12 clearance.....	36
11.5 Cable transition for opening angle $\leq 180^\circ$ , 12 clearance.....	37
12. Aluminium profile milling images .....	38
12.1 Keypad milling image .....	38
12.2 dLine touchkey milling image .....	39
12.3 Motor milling image.....	40
12.4 Cable transition for opening angle $\leq 110^\circ$ , aluminium 12 clearance.....	41
12.5 Cable transition for opening angle $\leq 180^\circ$ , aluminium 4 clearance, 12 clearance.....	42
12.6 Plunger contact.....	43
13. Composite milling images .....	44
13.1 Keypad milling image .....	44
13.2 dLine touchkey milling image.....	45
13.3 Motor milling image.....	46
13.4 Cable transition for opening angle $\leq 180^\circ$ , 12 clearance.....	47
13.5 Plunger contact.....	48
14. Disposal .....	49



# 1. Notes for using these installation instructions

## Target group

- › These installation instructions are intended exclusively for specialised companies and trained specialist personnel (e.g. carpenters, metalworkers for construction technology, window and glass façade installers).
- › The work described in these installation instructions may only be carried out by specialist personnel! This also applies in particular to electrical work, which may only be carried out by qualified electricians.

## Before starting installation ...

- › Read these installation instructions carefully before starting installation. Install all components professionally and only as described in these installation instructions and observe all safety and hazard information.
- › The use of system accessories not expressly approved by MACO, modifications or repair work not expressly authorised by MACO and improper servicing can lead to malfunctions and must be avoided.
- › Failure to comply with the installation, safety and hazard information described in these installation instructions does not guarantee the proper functioning of the fitting; this leads to the immediate loss of warranty, guarantee, compensation, product liability claims and other liability claims against MACO. MACO accepts no liability for any damage to persons or material resulting from improper installation or installation contrary to the instructions given in these installation instructions.
- › Failure to comply with the installation instructions will also result in the immediate loss of any outstanding claims arising from any existing warranty agreement.
- › Coordinate the required fastening material with the structure and the corresponding load and supplement it if necessary. Any fastening material supplied only fulfils part of the requirements.
- › To fasten the parts, use sufficiently long screws, which should extend into the steel reinforcement if possible in the case of plastic profiles.
- › Test doors and safety elements. The intactness and ease of movement of the doors must be ensured.
- › All work (installation, adjustment, etc.) must be carried out in a de-energised state.
- › Before installing the drive, check that the applicable temperature range is suitable for the environment.

## Usage instructions

- › These installation instructions are revised on an ongoing basis and the latest version is available for download at <https://www.maco.eu/assets/760322>. The QR code, which takes you directly to the latest version, and the creation date can be found at the end of these installation instructions.
- › All illustrations are only symbolic and serve only for better visualisation.
- › Unless otherwise stated, dimensions are given in **millimetres**.
- › Further information on our currently available products can be found on our website [www.maco.eu](http://www.maco.eu).
- › If in doubt, please consult your MACO contact person!
- › Please send any suggestions or ideas for improving our installation instructions by email to [feedback@maco.eu](mailto:feedback@maco.eu)

Protective note to restrict the use of documents in accordance with ISO 16016:

© Mayer & Co Beschläge GmbH.

## Applicable documents

The following documents must be observed in addition to these instructions and/or provide additional information:

- › Online catalogue eCat at <https://ecat.maco.eu/>
- › Operating and maintenance instructions for end users - order number [757585](#)
- › Operating and maintenance instructions for emergency exit and panic doors for end users - order number [760364](#)
- › PVC installation instructions - order number [757658](#)
- › Timber installation instructions - order number [757784](#)
- › Aluminium installation instructions - order number [757776](#)
- › Composite doors installation instructions - order number [759565](#)
- › Emergency exit and panic doors installation instructions - order number [760368](#)
- › Maintenance log for emergency exit and panic doors - order number [760372](#)

You can find the current version of all documents on our website at [www.maco.eu](http://www.maco.eu).

## The specialist company's obligation to provide information and instruction

Please ensure that you fulfil your obligation to inform and instruct the end user! As the distributor, you are obliged to deliver the window or door elements exclusively including the applicable operating and maintenance instructions and, if applicable, a sticker for deviating operating methods. We make these available to our customers in the download area of our website ([www.maco.eu/Downloads](http://www.maco.eu/Downloads)). End users must be trained accordingly.

### Retention of documents








Keep these installation instructions for future reference.


## 2. Safety and warning notices

These installation instructions contain safety instructions before a sequence of actions that could result in personal injury or material damage. The hazard prevention measures described must be strictly adhered to.

For the safety of personnel, there are safety instructions in the following 3 stages:

	Imminent danger! Failure to comply with such instructions will result in death or serious injury!
	Imminent danger from electrical voltage! Failure to comply with such instructions will result in death or serious injury!
	Possible imminent danger! Failure to comply with such instructions can result in death or serious injury!
	Warning against dangerous electrical voltage! Failure to comply with such instructions can result in death or serious injury!
	Possible imminent danger! Failure to comply with such instructions may result in minor or slight injuries!

In addition, installation steps that require special attention are labelled with the following note:

	Note to avoid material damage or errors when installing the fitting parts on the element.
---	---

## 3. Technical data

### 3.1 Motor for 3-latch automatic lock (104130)

It is recommended that the A-TS with motorised opening is only operated with tested and approved power supplies intended for this purpose. These are designed for an input voltage of 220 ... 240 V / 50 ... 60 Hz and provide an output voltage of 24 V DC 1 A with a dynamic overcurrent of 3 A for 500 ms / 7 A for 100 ms. Alternatively, third-party products must have an output voltage of 12 ... 24 V DC with at least 1.5 A.

Housing dimensions (W x H x D)	15.4 x 209 x 40.2 mm
Net weight	157 g
Rated voltage (SELV)	12 ... 24 V DC / 12 V AC
Standby consumption	14.2 mA at 24 V DC = 0.3 W
Operating temperature/ambient temperature	-10 ... +55 °C
Relative humidity	20 ... 80%, non-condensing
Storage temperature	-40 ... +85 °C
User groups	Private users, e.g. lay people, children
Usage environment	in covered and enclosed spaces
Application area	Industrial sector: no Residential area, business/commercial area, small businesses: yes
Inputs	1 potential-free contact (2 JST connectors)
Outputs	no
Protection type	not specified
Certificate	CE
Duty cycle	DC 50%
Protection class	III (SELV)



## 3.2 Comfort Motor 2.0 A-TS (482967)

It is recommended that the A-TS with motorised opening is only operated with tested and approved power supplies intended for this purpose. These are designed for an input voltage of 220 ... 240 V / 50 ... 60 Hz and provide an output voltage of 24 V DC 1 A with a dynamic overcurrent of 3 A for 500 ms / 7 A for 100 ms. Alternatively, third-party products must have an output voltage of 24 V DC with at least 1 A.

Housing dimensions (W x H x D)	15.4 x 209 x 40.2 mm
Net weight	157 g
Rated voltage (SELV)	24 V DC
Standby consumption	14.2 mA at 24 V DC = 0.3 W
Operating temperature/ambient temperature	-10 ... +55 °C
Relative humidity	20 ... 80%, non-condensing
Storage temperature	-40 ... +85 °C
User groups	Private users, e.g. lay people, children
Usage environment	in covered and enclosed spaces
Application area	Industrial sector: no Residential area, business/commercial area, small businesses: yes
Inputs	1 potential-free contact (2 JST connectors)
Outputs	no
Protection type	not specified
Certificate	CE
Duty cycle	DC 50%
Service life	100,000 cycles
Protection class	III (SELV)

### 3.3 Bluetooth module for A-TS + M-TS “BLE Module”

Dimensions (W x H x D)	8.3 x 88.6 x 21.2 mm
Net weight	18 g
Cable length	approx. 300 mm
Frequency range	2.40 GHz ... 2.48 GHz
Rated voltage (SELV)	12 ... 24 V DC
Rated current	0.01 A
Standby consumption	approx. 0.11 W
Operating temperature/ambient temperature	-10 ... +55 °C
Relative humidity	≤95%, non-condensing
Storage temperature	-25 ... +70 °C
User groups	Private users, e.g. lay people, children
Usage environment	in covered and enclosed spaces
Application area	Industrial sector: no Residential area, business/commercial area, small businesses: yes
Inputs	-
Outputs	1 potential-free output
Certificate	CE

### 3.4 UPS (uninterruptible power supply)

see installation instructions and UPS module data sheet - order no [759528](#)



### 3.5 Power supply

see installation instructions and data sheet power supplies 480276 and 480277 - order no [759529](#)



You can find all technical data in our online catalogue at <https://ecat.maco.eu/> (registration required).

## 4. Certificates and proof of performance

Certificates and proof of performance can be found at [www.maco.eu](http://www.maco.eu).

### Declarations of conformity

EU declarations of conformity or EC declarations of incorporation can be found at:



EU declaration of conformity  
Bluetooth module  
Instinct, A-TS, M-TS  
[www.maco.eu/assets/759742](http://www.maco.eu/assets/759742)



EU declaration of  
conformity  
Instinct, A-TS, M-TS power  
supply  
[www.maco.eu/assets/759745](http://www.maco.eu/assets/759745)



EU declaration of conformity  
UPS for A-TS and M-Ts  
[www.maco.eu/assets/759820](http://www.maco.eu/assets/759820)



EC declaration of  
incorporation  
A-TS motor  
[www.maco.eu/assets/759836](http://www.maco.eu/assets/759836)

## 5. Intended use

- › The A-TS motor is only permitted in combination with the A-TS automatic 3-latch lock.
- › Ensure that the components are in perfect condition before installation; damaged or defective components must not be used under any circumstances.

## 6. Reasonably foreseeable misuse



Improper installation, non-conforming or unusual use, the use of system accessories not expressly approved by MACO, modifications or repair work not expressly authorised by MACO and improper servicing can lead to malfunctions and must be avoided. Any measures not expressly authorised by MACO, shall result in the loss of all liability, warranty and any separately agreed guarantee claims.

Misuse exists, among others:

- › for use in rooms with high levels of dust, corrosive atmospheres, high electrostatic charge or damp rooms

## 7. Instructions for the processing of electrical and electronic components



**DANGER**

**NEVER WORK with live voltage - DANGER TO LIFE!**


The connection of electrical and electronic components may only be carried out by trained or instructed persons!

- › **The power supply must be disconnected during all electrical work! Disconnect all poles of electrical components from the supply voltage using an overvoltage category III switch before opening, installing or changing the set-up. Observe VDE 0100 for 230 V mains connection.**
- › **Before installation: A disconnecting device must be provided in the fixed installation to ensure that all poles are disconnected from the mains.**
- › **If a UPS module is used, the connection between the motor and the UPS module must also be disconnected.**
- › To prevent errors due to damaged cables, all milling/drilling holes in the area of the cable ducts must be carefully deburred! If possible, edge protection should be used.
- › When screwing them together, make sure that the cables are not damaged by the fastening screws!
- › Assembly and electrical installations must be carried out according to these instructions. Incorrect wiring can lead to the destruction of the electronics.
- › Before installing an electrical, electronic or electromechanical component, it must be checked whether the technical data is suitable for the environment (e.g. voltage, temperature range, etc.).


## 8. Installation of the motor on 3-latch automatic lock

### Packaging contents


- ① 1x driver
- ② 2x ⚙️ 20 M4 x 5 mm
- ③ 2x ⚙️ 20 M4 x 14 mm
- ④ 1x Motor for 3-latch automatic lock (104130) OR  
1x Comfort Motor 2.0 A-TS (482967)  
(identifiable by the label)



### Positioning



### Functionality



Carry out a function check with a test device!

## 9. Access solutions & interfaces


### 9.1 Overview

- ① **3-latch automatic lock with motorised opening**  
High level of security thanks to automatic locking of the steel hooks and the locking bolt.
- ② **Tamper-proof**  
Control unit protected against access by unauthorised persons.
- ③ Maximum convenience thanks to **motorised unlocking**.
- ④ **Plug & Play**  
Simple, non-interchangeable plug connection.
- ⑤ **Easy installation and removal** of the door thanks to plug-in cable transition.
- ⑥ **openDoor Touchkey dLine**



# Access solutions & interfaces

## 9.2 BLE module connection options for control via MACO SMARTPHONE APP



The INSTINCT app is available for free on iOS and Android. It is easy to install, activate with the QR code on the Admin Card and off you go. No complicated web-based programming is required.



## Access solutions & interfaces

### 9.3 Keypad

#### Cable assignment - cable transition

Plug & Play plug connection motor to:

- (A) Cable transition
- (B) Access solution
- (C) ⚡ Voltage supply
- (D) Loop for strain relief

Plug & play plug / cable assignment:

- (1) Brown operating voltage motor negative -
- (2) White operating voltage motor positive +
- (3) Green control voltage\* negative -
- (4) Yellow control voltage\* positive +
- ((3) + (4) Potential-free input)

\*The control voltage is required for buttons (touch pulse) and changeover switches (activation/deactivation of day release)  
See page 22/23.



To avoid damaging the cables, drill holes/  
millings must be deburred!



**WARNING**



Danger to life from electrical voltage!

Electrical connections (power supply, cables) may only be made by authorised personnel!



Flush-mounted power supply

Top hat rail power supply



**CAUTION**

It is recommended that the A-TS with motorised opening is only operated with tested and approved power supplies intended for this purpose (see pages 8, 9 and 10).

# Access solutions & interfaces

## 9.4 dLine touchkey

### Cable assignment - cable transition

Plug & Play plug connection motor to:

- (A) Cable transition
- (B) Access solution
- (C) ⚡ Voltage supply
- (D) Loop for strain relief

Plug & play plug / cable assignment:


- ① Brown operating voltage motor negative -
- ② White operating voltage motor positive +
- ③ Green control voltage\* negative -
- ④ Yellow control voltage\* positive +
- ((③ + ④) Potential-free input)

\*The control voltage is required for buttons (touch pulse) and changeover switches (activation/deactivation of day release)  
See page 22/23.






**Danger to life from electrical voltage!**

**Electrical connections (power supply, cables) may only be made by authorised personnel!**



Flush-mounted power supply  
Top hat rail power supply



 It is recommended that the A-TS with motorised opening is only operated with tested and approved power supplies intended for this purpose (see pages 8, 9 and 10).

## Access solutions & interfaces

### 9.5 dLine touchkey (hinge side)

#### Cable assignment - cable transition

Plug & Play plug connection motor to:

- (A) Cable transition
- (B) Access solution
- (C) ⚡ Voltage supply
- (D) Loop for strain relief

Plug & play plug / cable assignment:


- (1) Brown operating voltage motor negative -
- (2) White operating voltage motor positive +
- (3) Green control voltage\* negative -
- (4) Yellow control voltage\* positive +
- ((3) + (4) Potential-free input)

\*The control voltage is required for buttons (touch pulse) and changeover switches (activation/deactivation of day release)  
See page 22/23.




**Danger to life from electrical voltage!**

**Electrical connections (power supply, cables) may only be made by authorised personnel!**



- (E1) Cable controller - finger scan
- (E2) Cable controller - motor
- (E3) Cable transition - motor cable



It is recommended that the A-TS with motorised opening is only operated with tested and approved power supplies intended for this purpose (see pages 8, 9 and 10).

# Access solutions & interfaces

## 9.6 Somfy Smart lock controller

### Cable assignment - cable transition


Plug & Play plug connection motor to:

- (A) Cable transition
- (B) ⚡ Voltage supply
- (C) Loop for strain relief

Plug & play plug / cable assignment:

- (1) Brown operating voltage motor negative -
- (2) White operating voltage motor positive +
- (3) Green control voltage\* negative -
- (4) Yellow control voltage\* positive +
- ((3) + (4) Potential-free input)



A\_TS without lock monitoring  
DIP No. 3 = ON




**WARNING**

Danger to life from electrical voltage!

Electrical connections (power supply, cables) may only be made by authorised personnel!



Flush-mounted power supply  
Top hat rail power supply




**CAUTION**

It is recommended that the A-TS with motorised opening is only operated with tested and approved power supplies intended for this purpose (see pages 8, 9 and 10).

## Access solutions & interfaces

### 9.7 Frame-side circuit diagram



#### Cable assignment - cable transition



**WARNING**

Danger to life from electrical voltage!

Electrical connections (power supply, cables) may only be made by authorised personnel!



Flush-mounted power supply

Top hat rail power supply




**CAUTION**

It is recommended that the A-TS with motorised opening is only operated with tested and approved power supplies intended for this purpose (see pages 8, 9 and 10).

# Access solutions & interfaces


## 9.8 Touch pulse circuit diagram

### Cable assignment - cable transition



Danger to life from electrical voltage!

Electrical connections (power supply, cables) may only be made by authorised personnel!




It is recommended that the A-TS with motorised opening is only operated with tested and approved power supplies intended for this purpose (see pages 8, 9 and 10).

## Access solutions & interfaces

### 9.9 Changeover switch circuit diagram (motorised day position)


#### Cable assignment - cable transition



## WARNING

Danger to life from electrical voltage!

Electrical connections (power supply, cables) may only be made by authorised personnel!



Flush-mounted power supply

Top hat rail power supply



## CAUTION

It is recommended that the A-TS with motorised opening is only operated with tested and approved power supplies intended for this purpose (see pages 8, 9 and 10).


## Access solutions & interfaces

### 9.10 UPS (uninterruptible power supply) connection diagram

The use of the MACO UPS (item no. 480987) is recommended by MACO and bridges common, short-term power failures without functional restrictions. The bridging time depends on the actual system configuration. In the unlikely event of a power failure during a motorised opening or closing operation, the mechanism may jam. The lock moves to the desired position with the UPS. Without a UPS, the A-TS can be operated manually using a key or handle (from the inside) in the event of a power failure when closed or open.





For UPS operation, at least one additional consumer (BLE module, access control,...) must be connected. Otherwise, the UPS will go into standby mode and will NOT be active in the event of a power failure.




**Danger to life from electrical voltage!**

**Electrical connections (power supply, cables) may only be made by authorised personnel!**



It is recommended that the A-TS with motorised opening is only operated with tested and approved power supplies intended for this purpose (see pages 8, 9 and 10).




## Access solutions & interfaces

### 9.11 Plunger contact secureConnect dLine touchkey


Plug & Play plug connection motor to:

- Ⓐ Adapter cable for motor to dLine control unit (item no. 482148)
- Ⓑ Adapter cable for plunger contact to motor (item no. 478821)
- Ⓒ dLine access control




## 10. Timber profile milling images

### 10.1 Keypad milling image




## Timber profile milling images

### 10.2 dLine touchkey milling image



# Timber profile milling images

## 10.3 Motor milling image




- (A) dLine control unit for access solutions
- (B) Cable duct for Comfort solution
- (C) Cable for openDoor access solutions

\* Milling for motor

\*\* Milling for dLine control unit

## Timber profile milling images

### 10.4 Motor milling image with BLE module






Ⓐ BLE module

\* Milling for motor

\*\* Milling for BLE module


# Timber profile milling images

## 10.5 Cable transition for opening angle $\leq 110^\circ$ , 12 clearance




## Timber profile milling images

### 10.6 Cable transition for opening angle $\leq 180^\circ$ , 4 clearance, 12 clearance




# Timber profile milling images

## 10.7 Plunger contact





## 11. PVC profile milling images

### 11.1 Keypad milling image







# PVC profile milling images

## 11.2 dLine touchkey milling image



# PVC profile milling images

## 11.3 Motor milling image




- (A) dLine control unit for access solutions
- (B) Cable for openDoor access solutions

\* Milling for motor




# PVC profile milling images

## 11.4 Cable transition for opening angle $\leq 110^\circ$ , 12 clearance



## PVC profile milling images


### 11.5 Cable transition for opening angle $\leq 180^\circ$ , 12 clearance



Due to the different hinge designs and the resulting insertion axes, the position of the cable tray (dimension X) and the cover plate (dimension Y) must be determined independently!


## 12. Aluminium profile milling images

### 12.1 Keypad milling image




# Aluminium profile milling images

## 12.2 dLine touchkey milling image





# Aluminium profile milling images

## 12.3 Motor milling image






# Aluminium profile milling images

## 12.4 Cable transition for opening angle $\leq 110^\circ$ , aluminium 12 clearance



## Aluminium profile milling images


### 12.5 Cable transition for opening angle $\leq 180^\circ$ , aluminium 4 clearance, 12 clearance



Due to the different hinge designs and the resulting insertion axes, the position of the cable tray (dimension X) and the cover plate (dimension Y) must be determined independently!


# Aluminium profile milling images

## 12.6 Plunger contact




## 13. Composite milling images

### 13.1 Keypad milling image




## Composite milling images

### 13.2 dLine touchkey milling image



# Composite milling images

## 13.3 Motor milling image




- (A) dLine control unit for access solutions
- (B) Cable duct for Comfort solution
- (C) Cable for openDoor access solutions

\* Milling for motor

\*\* Milling for dLine control unit


## Composite milling images

### 13.4 Cable transition for opening angle $\leq 180^\circ$ , 12 clearance



# Composite milling images

## 13.5 Plunger contact






## 14. Disposal

The disposal must be carried out in accordance with local regulations and laws.

# Would you like everything from a single source?

With us you get complete solutions for your large surfaces, windows and doors – for timber, PVC and aluminium. Experience our versatile systems range with comprehensive service included. Discover more on our website [www.maco.eu](http://www.maco.eu), or contact your MACO customer advisor.



**MACO near you:**  
[www.maco.eu/en-GB/Contact](http://www.maco.eu/en-GB/Contact)



TECHNOLOGY IN MOTION



This document is revised on an ongoing basis.  
You can find the current version at <https://www.maco.eu/assets/760322>,  
or by scanning the QR code.

Created: 04/2026 - Changed: 06/2026  
Order no. 760322  
All rights and modifications reserved.