




MACO RAIL-SYSTEMS

SLIDING HARDWARE



ASSEMBLY INSTRUCTIONS

HS COMFORT CLOSE / COMFORT STOP concealed with reinforcement VS9620 Salamander evolutionDrive HST 82

Table of contents

Important instructions	3
Function	3
Fittings overview	4 - 5
Preparation frame - Example: scheme A and C	6
Preparation sash	7
Mounting Comfort Close/Comfort Stop	8
Mounting sash and frame	9
Reference dimension	9
Adjustment options	10
Mounting cover frame piece	10
Limit opening width	11
Technical data	11



Important instructions


Target group

This documentation is intended exclusively for specialist companies and certified specialists. The work described herein must only be carried out by certified specialists.

Usage and safety information

In addition to this information, the profile-dependent assembly instructions for HS-Hardware Salamander evolution Drive 82 PVC, Order No. 758545EN, must be complied with. In the Comfort Close assembly instructions, only the differences from the above document are described. Mount all hardware parts professionally as described in this manual and observe all safety instructions.


Function



Fittings overview

Pos. Description Comfort Close 15.1 15.2 **Comfort Stop** 16.1 Packer housing 16.2 Frame piece Cover frame piece 16.3 Packer frame piece 16.4 Packer frame piece (3 mm) 16.5

Note: All measurements in this document are indicated in millimetres.



Screws are not included in scope of delivery.
Respective specifications represent a recommendation, only.




Fittings overview

Items per sliding sash

	Article description				Item Code
1	Comfort Close 15.1 ²⁾	size 1	≤ 200 kg ≤ 30 N	sash weight Sliding force	300359
		size 2	> 200 300 kg ≤ 50 N	sash weight Sliding force	300360
1 ×)	Comfort Stop 15.2 z)	size 1	≤ 200 kg ≤ 30 N	sash weight Sliding force	304052
		size 2	> 200 300 kg ≤ 50 N	sash weight Sliding force	304053
	Accessories 501 Comfort Close + Comfort Stop 16.1, 16.4, 16.5			305132	
1	Accessories 501 Comfort Close + Comfort Stop 16.1, 16.4, 16.5				
1	Frame piece, adjustable 16.2				
1	1 Cover frame piece 16.3				

x) optional z) Colour of damper: size 1 - black, size 2 - silver-grey

Preparation frame - Example: scheme A and C






Preparation sash

> Carry out sash milling for comfort close on non-handle side and/ or for comfort stop on handle side...




The reinforcement "VS9620" has to be within the area of comfort close respectively comfort stop (slide in max. 105 mm to outer edge of sash).



Mounting Comfort Close/Comfort Stop

- > (1) Comfort Close respectively Comfort Stop has to be pretensioned.
- > (2) Clip packer onto the housing of the Comfort Close and/or onto the housing of the Comfort Stop.
- > (3) Mount the Comfort Close respectively Comfort Stop with 2 screws 4.8 x 25 each at the sash.





Mounting sash and frame





Attention: Risk of injury due to fallen sash!

To avoid the risk of injury, perform the following steps with two workers.

Example: scheme A; scheme C accordingly


- > (1) Set sash into frame as shown.
- > (2) Put both guides (4.10) onto the slider (4.12) and fasten by means of screws 4.8 x 45 into the dowels.





Reference dimension


- To check the height of the frame piece, swivel in the sash, lift it and slide into closing position.
- Measure reference dimension within the range of the comfort close respectively comfort stop (desired value = 9 mm).
- If necessary, slide the sash aside and compensate deviation to the reference dimension by adjustment of the frame piece (refer to "Adjustment options".
- > Fasten guide track on fixed sash side.




Adjustment options

In case of inaccuracy concerning position of the frame piece, the reference dimension concerning the height of the frame piece and the end position of the sash related to the frame can be adjusted. To do this, the sash has to be opened.

- > (1) Correction of the lateral position (+/- 5 mm):
 - (1.1) Loosen screw by means of Torx 25,
 - (1.2) Slide frame piece into the desired direction:
 - 0 5 mm: closing of sash will be shifted in direction of handle side;
 - 0 + 5 mm: closing of sash will be shifted in direction of non-handle side.
- > (1.3) Fasten screw with max. 3 Nm.
- > (2) Correction of the height of the frame piece (+ 3 mm) with Torx 15.




Mounting cover frame piece





Limit opening width



Technical data

Range of application scheme A:

Sash width (FB)	740 – 3330 mm
FB _{min.} for 2x Comfort Close	890 mm
Sash height (FH)	755/765 – 2870/2880 mm
Outer frame width (RAB)	acc. to profile manufacturer's specifications
Sash weight or sliding force without	size 1: max. 200 kg or
Comfort Close and Comfort Stop	max. 30 N
	size 2: max. 300 kg or
	max. 50 N
	(further sizes on request)

Depending on version of the profile sealing to be used, it can happen, that the sash cannot close completely.

Dimensions (W x H x D)	
Comfort Close	336 mm x 27.5 mm x 22 mm
Comfort Stop	336 mm x 27.5 mm x 22 mm
Soft move-in	starting approx. 100 mm off the closing edge
Increase of sliding force	size 1: by 25 N (black)
with Comfort Close or Comfort Stop	size 2: by 45 N (silver-grey)

Range of application is depending on used profile systems. Specifications of profile manufacturers to be observed.

You want everything from a single source?

We provide you with complete solutions for sliding doors, windows and doors — for timber, PVC and aluminium. Experience our versatile system offer, comprehensive service included. Discover more of this on our website **www.maco.eu** or contact your MACO representative.





www.maco.eu/contact



TECHNOLOGY IN MOTION

