



Beipackzettel jedem Artikel beifügen! /
Include a copy of this note with each item!
(Download www.maco.eu)



Datenblatt - Anschlusskabel mit JST Stecker / Data sheet - connection cable with JST plug

Bestimmungsgemäße Verwendung

Das Anschlusskabel mit dem JST-Stecker wird als steckbares Verbindungskabel zwischen Fensterrahmen und Fensterflügel eingesetzt. Er darf nur zu diesem Zweck eingebaut und verwendet werden!

Einbau und Anschluss des Anschlusskabels darf nur durch Fachpersonal erfolgen!

Intended purpose

The connecting cable with JST plug is deployed as a pluggable connection cable between window frame and window casement. It is only permitted to be installed and used for this purpose!

Assembly / installation of the connection cable is only permitted to be carried out by skilled personnel!

①	Betriebsspannung - / Operation voltage -
②	Betriebsspannung + / Operation voltage +
③	Steuerspannung - / Control voltage -
④	Steuerspannung + / Control voltage +



Technische Daten / Technical specifications

Stecker / Plugs	JST PAP-04V-S
Leitung / Cable	LiF9Y11Y 6 x 0,34 mm ²
Leitungslänge / Length of cable	0,15 m, 3,5 m oder 10 m / 0,15 m, 3,5 m or 10 m
Kabelbelegung / Cable assignment	
braun / brown ①	-12 V - 24 VDC / -12 V - 18 VAC / -12 V to 24 VDC / -12 V to 18 VAC
weiß / white ②	+12 V - 24 VDC / +12 V - 18 VAC / +12 V to 24 VDC / +12 V to 18 VAC
grün / green ③	Steuerspannung - / Control voltage -
gelb / yellow ④	Steuerspannung + / Control voltage +
Leiterwiderstand / Line resistance	Max. 57 Ohm/km
Strom / Current	Max. 3,0 A
Temperatur / Temperature	-20 °C bis +70 °C / -4 °F to 158 °F

