

MACO RAIL-SYSTEMS SLIDING HARDWARE

ASSEMBLY INSTRUCTIONS

HS COMFORT CLOSE / COMFORT STOP concealed Timber, Guide Track flush-mounted J.

Table of contents

Important instructions	3
Function	3
Fittings overview	4 - 5
Preparation frame - Example: scheme A and C	6
Preparation sash	7
Mounting Comfort Close/Comfort Stop	8
Mounting sash and frame	9
Reference dimension	9
Adjustment options	10
Mounting cover frame piece	10
Technical data	11




Important instructions

Target group

This documentation is intended exclusively for specialist companies and certified specialists. The work described herein must only be carried out by certified specialists.

Usage and safety information


In addition to this information, the profile-dependent assembly instructions for HS-Hardware System A, C, G, K Timber, Order No. 757077EN, must be complied with. In the Comfort Close assembly instructions, only the differences from the above document are described. Mount all hardware parts professionally as described in this manual and observe all safety instructions.




Fittings overview

Pos. Description

- 6.1 Guide Track
- 15.1 Comfort Cose
- 15.2 Comfort Stop
- 16.1 Packer housing
- 16.2 Frame piece
- 16.3 Cover frame piece








Fittings overview

Items per sliding sash

Α	Article description			Item Code	
	Comfort Close 15.1 ^{z)} size 2	size 1	≤ 200 kg ≤ 30 N	sash weight sliding force	300359
1		> 200 300 kg ≤ 50 N	sash weight sliding force	300360	
1 ^{x)}	Comfort Stop 15.2 z)	size 1	≤ 200 kg ≤ 30 N	sash weight sliding force	304052
		size 2	> 200 300 kg	sash weight	304053
1	Frame piece, adjustable 16.2		≤ 50 N	sliding force	305134
1	Cover frame piece 16.3				304816

x) optional z) Colour of damper: size 1 - black, size 2 - silver-grey


Preparation frame - Example: scheme A and C






Preparation sash

> Carry out sash milling for Comfort Close on non-handle side and/or for Comfort Stop on handle side.



Mounting Comfort Close/Comfort Stop

- > (1) Comfort Close respectively Comfort Stop has to be pretensioned.
- > (2) Mount the Comfort Close respectively Comfort Stop with 2 screws 4.5 x 25 each at the sash.






Mounting sash and frame




Attention: Risk of injury due to fallen sash! To avoid the risk of injury, perform the following steps with two workers.

Example: scheme A; scheme C accordingly


- > (1) Set down the sliding sash onto the running track in the area of the fixed sash and swivel it into the element.
- > (2) Insert handle side guide onto the slider (4.12) (handle side) and push into the sash groove. Screw in with 4.5×60 and $\emptyset 4 \times 30$ screws.
- > (3) Insert rebate guide onto the slider (non-handle side) and push into the sash groove. Screw in with Ø 4 x 30 screws.





Reference dimension


- > To check the height of the frame piece, swivel in the sash, lift it and slide into closing position.
- Measure reference dimension within the range of the comfort close respectively comfort stop (desired value = 9 mm).
- If necessary, slide the sash aside and compensate deviation to the reference dimension by adjustment of the frame piece (refer to "Adjustment options".



Adjustment options


In case of inaccuracy concerning position of the frame piece, the reference dimension concerning the height of the frame piece and the end position of the sash related to the frame can be adjusted. To do this, the sash has to be opened.

- > (1) Correction of the lateral position (+/- 5 mm):
 - (1.1) Loosen screw by means of Torx 25,
 - (1.2) Slide frame piece into the desired direction:
 - 0 5 mm: closing of sash will be shifted in direction of handle side;
 - 0 + 5 mm: closing of sash will be shifted in direction of non-handle side
- > (1.3) Fasten screw with max. 3 Nm.
- > (2) Correction of the height of the frame piece (+ 3 mm) with Torx 15.



Note: Adjustments may be changed after glazing the sash and mounting the frame!

Mounting cover frame piece





Technical data

Range of application scheme A:

Sash width (FB)	720 – 3385 mm
FB _{min.} for 2x Comfort Close	885 mm
Sash height (FH)	745 – 2870 mm
Outer frame width (RAB)	6500 mm
Sash weight or sliding force without Comfort Close and Comfort Stop	size 1: max. 200 kg or max. 30 N size 2: max. 300 kg or max. 50 N (further sizes on request)


Depending on version of the profile sealing to be used, it can happen, that the sash cannot close completely.

Dimensions (W \times H \times D)	
Comfort Close	336 mm x 27.5 mm x 22 mm
Comfort Stop	336 mm x 27.5 mm x 22 mm
Soft move-in	starting approx. 100 mm off the closing edge
Increase of sliding force with Comfort Close or Comfort Stop	size 1: by 25 N (black) size 2: by 45 N (silver-grey)

Range of application is depending on used profile systems. Specifications of profile manufacturers to be observed.

You want everything from a single source?

We provide you with complete solutions for sliding doors, windows and doors – for timber, PVC and aluminium. Experience our versatile system offer, comprehensive service included. Discover more of this on our website **www.maco.eu** or contact your MACO representative.





MACO near you:

www.maco.eu/contact

TECHNOLOGY IN MOTION



This print document is revised regularly. The latest version is available at <u>https://www.maco.eu/assets/757799</u> or by scanning the QR code.